

# NEROLAC IMPRESSIONS KASHMIR MATT PREMIUM LUXURY EMULSION



Colours that Care













#### PRODUCT DESCRIPTION

Nerolac Impressions Kashmir Matt offers best in class Smooth Matt Finish that Hides Wall Imperfections\* and provides Luxury matt Finish to Walls. It is based on Silver Ion Technology that kills 99% of bacteria on the painted surface and gives safe & healthy environment at home. The whiteness, opacity, washability, stain resistance, flow & levelling, ease of application, anti-viral performance, anti-fungal performance & anti-bacterial performance are outstanding, thereby creating a high-class smooth matt finish that keeps the wall awe-inspiring for years.

\*It depends upon the quantum of wall imperfections & quality of surface preparation.

#### PERFORMANCE FEATURES & BENEFITS



Luxury Matt finish



Excellent Flow and Leveling



Luxurious, Smooth, & Durable Finish



Kills 99% Germs



Hides Wall Imperfections



Anti-Viral



High-Definition colours



Anti-Bacterial



Excellent Stain Resistance



Anti-Fungal



**Excellent Washability** 



Low VOC & Low Odour

## SURFACE PREPARATION

- Rub the surface using a suitable abrasive paper and wipe it off to ensure that the surface is clean, dry and free from dirt, grease, wax or any other defective or poorly adhering material.
- Treat fungus affected areas with Nerolac Fungicidal Solution and allow it to react for 6-8 Hrs
- Apply 1 coat of Nerolac Perma Damp ProtectInterior at 50% dilution. (OR) Self-Priming at 100% dilution.
- Apply 2 coats Nerolac Acrylic Wall Putty or Nerolac Cement Putty to level the dents, dry, followed by sanding with emery paper 180 and wipe clean.
- Apply 1 coat of Nerolac Perma Damp Protect

  5. Interior at 50% dilution. (OR) Self-Priming at 100% dilution.
- Sand the surface with Emery paper no.320 and clean the surface with cloth before painting.
  Finally, apply 2-3 coats of Nerolac Impressions Kashmir Matt at 40-50% dilution. Dark shade ma require additional coat for hiding.

## RECOMMENDED USAGE

Nerolac Impressions Kashmir Matt Luxury Emulsion is designed for application on new as well as previously painted interior surfaces such as plaster, brickwork, cement rendering, concrete, hard boards, etc.

## APPLICATION (FOR NEW MASONRY SURFACES)

- 1. Primer\*\*(1 coat), Dry for 4-6 Hrs.
- 2. Putty## (1st coat), Dry for 6-8 Hrs.
- 3. Putty## (2nd coat), Dry for 6-8 Hrs
- 4. Primer\*\*(1 coat), Dry for 4-6 Hrs.

# 5. Finish Nerolac Impressions Kashmir Matt (2-3 coats), Dry min for 3-4 Hrs. in between coats.

Sand the surface with Emery paper and clean before application of subsequent coat.

- "Nerolac Perma Damp Protect Interior at 50% dilution. (OR) Self- Priming at 100% dilution.
- ##Nerolac Wall putty or Nerolac Cement putty.
- For Repainting on Smooth Lime/Distemper/Emulsion/Enamel Masonry Surfaces, skip steps 1, 2 & 3 and start with step 4.

### PRECAUTIONS

- Refer MSDS for "Nerolac Impressions Kashmir Matt" for safety measures & precautions.
- Store in well ambient conditions, ventilated locations & away from the source of ignition and fire.
- 3. Keep away from children.
- 4. In case of eye/skin contact, wash with plenty of water.
- 5. Inhalation/Injection will cause danger. In either case, move to fresh air & consult medical practitioners in both the cases.
- 6. Do not apply when ambient temperature might drop to level below 10°C within 4 h. of application.
- 7. New plaster should be allowed to cure for minimum 12 weeks.
- 8. Avoid extra thinning for better results.
- g. Can be tinted with Nerolac Hi-Power Universal Stainer before thinning. Do not add more than 5% of Nerolac Hi-Power Universal Stainer. Stir the tinted paint well, after tinting & before application.
- 10. The container must be tightly closed when not in use, Stir well and strain before use.
- 11. Use safety equipment's like rubber or polythene gloves, safety goggles/glasses & face mask.



Note: Actual coverage may vary depending on method & condition of application, surface roughness & surface.

#### POST APPLICATION INSTRUCTIONS

For removing stains, sponge clean with mild soap solution and wipe clean. Please allow 2 weeks of drying time to freshly painted wall for it to be ready for stain removal/cleaning.



## DISCLAIMER

The product information and application details given by the company has been provided in good faith and is meant to serve only as a general guideline during usage. The performance claims made are based on the tests carried out under controlled conditions and our past experience with the type of products. Therefore, actual performance will depend on local factors prevailing at that point of time. Users are advised to carry-out sample tests by taking trials to ensure the suitability of products for their requirement prior to full-scale usage of our products.

The Company is not liable for factors beyond its control such as application during adverse climatic conditions, use of improper application tools/techniques and surface preparation, any structural defects, or the inferior quality of materials other than paints. The warranty/guarantee clauses shall accordingly be amended.